

1					2				
MODEL NO.					MODEL NAME				
56000402					ASSY, TOP PLATE, TWO SIDED, 750 PSI				
NO.	QTY	PART NO.	DESCRIPTION		FILTER KIT				
1	1	10101602	ASSY, ACC, 3.6 CI, 750 PSI		NO				
2	2	30000144	CONNECTOR, 1/4 FLRL TB - SAE 4		NO				
3	3	30601144	PLUG, SOCH, SAE 4		NO				
4	4	30601166	PLUG, SOCH, SAE 6		NO				
5	1	30772760	COUPLER, QD, SAE 6, MALE, FLUSH		NO				
6	1	30871166	ASSY, ADAPTER, SAE 6, MALE		NO				
7	1	31050011	FILTER, DISC, SAE 6, 25 MICRON		YES				
8	2	31050013	DIFFUSER, DISK, SAE 6		YES				
9	1	39002009	O-RING, (-012)		YES				
10	2	39054010	BU RING, (-012)		YES				
11	1	55250001	O-RING, (-010)		NO				
12	1	70101700	ASSY, VALVE, UNLOAD		NO				
13	1	70101703	ASSY, VALVE, UNLOAD, BLEEDER		NO				
14	1	70343792	VALVE, CHECK, SAE 4, 30 PSI		NO				
15	2	72322155	GAUGE, PRESS, HYDR, 6000PSI, CBM, SAE 4, 1.66"		NO				
N/A	N/A	62560004	KIT, FILTER, TP, SAE 6, 25 MICRON		NOTED				
N/A	N/A	IS5604	INSTRUCTION SHEET		N/A				

O-RING PROVIDED WITH CHECK VALVE

APPLY LUBRICANT TO ALL SEALS PRIOR TO INSTALLATION
DO NOT USE SILICONE TYPE LUBRICANTS.

PARTS LIST

VEKTEK
VEKTEK, INC.
1334 E. SIXTH AVE. P.O. BOX 625
EMPORIA, KS. 66801 U.S.A.

ASSEMBLIES AFFECTED
56000402

SIZE
A

PL5614

REV
G

G	4189	RELEASE	JDW	05/26/20
REV	IN ACCORDANCE WITH ECN	EFFECTIVE DATE	REVISED BY	DATE
DRW BY: ABC	DRAWING STATUS: Released			
DATE: XX-YY-ZZ	PRODUCTION APPROVED FOR RELEASED STATUS ONLY			

1

2

FORM FEG035_PL_ASIZE, REV. B

SHEET 1 OF 1

Vektek, Inc. 1334 East Sixth Ave. P.O. Box 625 Emporia, Ks. 66801 U.S.A.	Instruction Sheet	IS-	5604	
		REV:	A I.A.W. ECN 1352	
		BY/DATE:	M Say	08/01/05
		APPR/DATE:	R. Hausler	10-4-05
Title Operating Instructions: Two and Four Sided Top Plate Assemblies				

Read all instructions before operating

1. Shut off the power supply and release any pressure on the output line.
2. Close all valves on the top plate.
3. Connect the power supply to the top plate, through the quick disconnect coupling.
4. Open the valve on the fixture where the part will be changed out. Change out the part and close the valve.
5. Pressurize the fixture by holding the pendant rocker switch in the clamp position. After the system is pressurized, release the switch.
6. Rotate the tombstone to the next fixture to be loaded.
7. Repeat steps four, five and six until all fixtures are reloaded.
8. Disconnect the power supply from the tombstone.

NOTE:

Tombstone fixtures may be loaded or unloaded independently, without loss of pressure to adjacent fixtures.