

No.	MODEL	PARTS LIST	STD. SEAL KIT	SPRING KIT	FKM SEAL KIT	REPAIR KIT
1	L1-0115-00-H	LPL-1000	L6-0100-02	L6-1100-01	N/A	N/A
2	L1-0115-00-L	LPL-1000	L6-0100-02	L6-1100-00	N/A	N/A
3	L1-0116-00-H	LPL-1001	L6-0100-04	L6-1100-03	N/A	N/A
4	L1-0116-00-L	LPL-1001	L6-0100-04	L6-1100-02	N/A	N/A
5	L1-0120-00-H	LPL-1020	L6-0100-08	L6-1100-21	N/A	N/A
6	L1-0120-00-L	LPL-1020	L6-0100-08	L6-1100-20	N/A	N/A
7	L1-0122-00-H	LPL-1022	L6-0100-10	L6-1100-25	N/A	N/A
8	L1-0122-00-L	LPL-1022	L6-0100-10	L6-1100-24	N/A	N/A
9	L1-0215-00-H	LPL-1002	L6-0100-03	L6-1100-05	N/A	N/A
10	L1-0215-00-L	LPL-1002	L6-0100-03	L6-1100-04	N/A	N/A
11	L1-0216-00-H	LPL-1003	L6-0100-05	L6-1100-09	N/A	N/A
12	L1-0216-00-L	LPL-1003	L6-0100-05	L6-1100-08	N/A	N/A
13	L1-0220-00-H	LPL-1021	L6-0100-09	L6-1100-23	N/A	N/A
14	L1-0220-00-L	LPL-1021	L6-0100-09	L6-1100-22	N/A	N/A
15	L1-0222-00-H	LPL-1023	L6-0100-11	L6-1100-27	N/A	N/A
16	L1-0222-00-L	LPL-1023	L6-0100-11	L6-1100-26	N/A	N/A
17	L1-0310-00-H	LPL-1012	L6-0100-07	L6-1100-19	N/A	N/A
18	L1-0310-00-L	LPL-1012	L6-0100-07	L6-1100-18	N/A	N/A
19	L1-0312-00-H	LPL-1013	L6-0100-06	L6-1100-17	N/A	N/A
20	L1-0312-00-L	LPL-1013	L6-0100-06	L6-1100-16	N/A	N/A
21	L1-0315-00-H	LPL-1004	L6-0100-00	L6-1100-01	N/A	N/A
22	L1-0315-00-L	LPL-1004	L6-0100-00	L6-1100-00	N/A	N/A
23	L1-0316-00-H	LPL-1005	L6-0100-01	L6-1100-03	N/A	N/A
24	L1-0316-00-L	LPL-1005	L6-0100-01	L6-1100-02	N/A	N/A
25	L1-0410-00-H	LPL-1014	L6-0100-07	L6-1100-15	N/A	N/A
26	L1-0410-00-L	LPL-1014	L6-0100-07	L6-1100-14	N/A	N/A
27	L1-0412-00-H	LPL-1015	L6-0100-06	L6-1100-13	N/A	N/A
28	L1-0412-00-L	LPL-1015	L6-0100-06	L6-1100-12	N/A	N/A
29	L1-0415-00-H	LPL-1006	L6-0100-00	L6-1100-07	N/A	N/A
30	L1-0415-00-L	LPL-1006	L6-0100-00	L6-1100-06	N/A	N/A
31	L1-0416-00-H	LPL-1007	L6-0100-01	L6-1100-11	N/A	N/A
32	L1-0416-00-L	LPL-1007	L6-0100-01	L6-1100-10	N/A	N/A
33	L1-0510-00-H	LPL-1016	L6-0100-07	L6-1100-19	N/A	N/A
34	L1-0510-00-L	LPL-1016	L6-0100-07	L6-1100-18	N/A	N/A
35	L1-0512-00-H	LPL-1017	L6-0100-06	L6-1100-17	N/A	N/A
36	L1-0512-00-L	LPL-1017	L6-0100-06	L6-1100-16	N/A	N/A
37	L1-0515-00-H	LPL-1008	L6-0100-00	L6-1100-01	N/A	N/A
38	L1-0515-00-L	LPL-1008	L6-0100-00	L6-1100-00	N/A	N/A
39	L1-0516-00-H	LPL-1009	L6-0100-01	L6-1100-03	N/A	N/A
40	L1-0516-00-L	LPL-1009	L6-0100-01	L6-1100-02	N/A	N/A
41	L1-0610-00-H	LPL-1018	L6-0100-07	L6-1100-15	N/A	N/A
42	L1-0610-00-L	LPL-1018	L6-0100-07	L6-1100-14	N/A	N/A
43	L1-0612-00-H	LPL-1019	L6-0100-06	L6-1100-13	N/A	N/A
44	L1-0612-00-L	LPL-1019	L6-0100-06	L6-1100-12	N/A	N/A
45	L1-0615-00-H	LPL-1010	L6-0100-00	L6-1100-07	N/A	N/A
46	L1-0615-00-L	LPL-1010	L6-0100-00	L6-1100-06	N/A	N/A

No.	MODEL	PARTS LIST	STD. SEAL KIT	SPRING KIT	FKM SEAL KIT	REPAIR KIT
47	L1-0616-00-H	LPL-1011	L6-0100-01	L6-1100-11	N/A	N/A
48	L1-0616-00-L	LPL-1011	L6-0100-01	L6-1100-10	N/A	N/A
49	L1-4025-00-L	LPL-1400	L6-0142-50	N/A	N/A	N/A
50	L1-4025-00-R	LPL-1401	L6-0142-50	N/A	N/A	N/A
51	L1-4025-10	LPL-1424	L6-0142-50	N/A	N/A	L6-2142-50
52	L1-4032-00-L	LPL-1402	L6-0143-20	N/A	N/A	N/A
53	L1-4032-00-R	LPL-1403	L6-0143-20	N/A	N/A	N/A
54	L1-4032-10	LPL-1425	L6-0143-20	N/A	N/A	L6-2143-20
55	L1-4040-00-L	LPL-1404	L6-0144-00	N/A	N/A	N/A
56	L1-4040-00-R	LPL-1405	L6-0144-00	N/A	N/A	N/A
57	L1-4040-10	LPL-1426	L6-0144-00	N/A	N/A	L6-2144-00
58	L1-4050-00-L	LPL-1406	L6-0145-00	N/A	N/A	N/A
59	L1-4050-00-R	LPL-1407	L6-0145-00	N/A	N/A	N/A
60	L1-4050-10	LPL-1427	L6-0145-00	N/A	N/A	L6-2145-00
61	L1-4063-00-L	LPL-1408	L6-0146-30	N/A	N/A	N/A
62	L1-4063-00-R	LPL-1409	L6-0146-30	N/A	N/A	N/A
63	L1-4063-10	LPL-1428	L6-0146-30	N/A	N/A	L6-2146-30
64	L1-4080-00-L	LPL-1410	L6-0148-00	N/A	N/A	N/A
65	L1-4080-00-R	LPL-1411	L6-0148-00	N/A	N/A	N/A
66	L1-4080-10	LPL-1429	L6-0148-00	N/A	N/A	L6-2148-00
67	L1-4125-00-L	LPL-1412	L6-0142-50	N/A	N/A	N/A
68	L1-4125-00-R	LPL-1413	L6-0142-50	N/A	N/A	N/A
69	L1-4125-10	LPL-1430	L6-0142-50	N/A	N/A	L6-2142-50
70	L1-4132-00-L	LPL-1414	L6-0143-20	N/A	N/A	N/A
71	L1-4132-00-R	LPL-1415	L6-0143-20	N/A	N/A	N/A
72	L1-4132-10	LPL-1431	L6-0143-20	N/A	N/A	L6-2143-20
73	L1-4140-00-L	LPL-1416	L6-0144-00	N/A	N/A	N/A
74	L1-4140-00-R	LPL-1417	L6-0144-00	N/A	N/A	N/A
75	L1-4140-10	LPL-1432	L6-0144-00	N/A	N/A	L6-2144-00
76	L1-4150-00-L	LPL-1418	L6-0145-00	N/A	N/A	N/A
77	L1-4150-00-R	LPL-1419	L6-0145-00	N/A	N/A	N/A
78	L1-4150-10	LPL-1433	L6-0145-00	N/A	N/A	L6-2145-00
79	L1-4163-00-L	LPL-1420	L6-0146-30	N/A	N/A	N/A
80	L1-4163-00-R	LPL-1421	L6-0146-30	N/A	N/A	N/A
81	L1-4163-10	LPL-1434	L6-0146-30	N/A	N/A	L6-2146-30
82	L1-4180-00-L	LPL-1422	L6-0148-00	N/A	N/A	N/A
83	L1-4180-00-R	LPL-1423	L6-0148-00	N/A	N/A	N/A
84	L1-4180-10	LPL-1435	L6-0148-00	N/A	N/A	L6-2148-00
85	L1-6025-00	LPL-1600	L6-0162-50	N/A	N/A	N/A
86	L1-6032-00	LPL-1601	L6-0163-20	N/A	N/A	N/A
87	L1-6040-00	LPL-1602	L6-0164-00	N/A	N/A	N/A
88	L1-6050-00	LPL-1603	L6-0165-00	N/A	N/A	N/A
89	L1-6063-00	LPL-1604	L6-0166-30	N/A	N/A	N/A
90	L2-1121-00	MPLV-4200	60-2112-00	N/A	N/A	N/A
91	L2-1121-01	MPLV-4201	60-2112-00	N/A	N/A	N/A
92	L2-1121-02	MPLV-4202	60-2112-01	N/A	N/A	N/A

No.	MODEL	PARTS LIST	STD. SEAL KIT	SPRING KIT	FKM SEAL KIT	REPAIR KIT
93	L2-1121-03	MPLV-4203	60-2112-01	N/A	N/A	N/A
94	L2-1121-04	MPLV-4204	60-2112-02	N/A	N/A	N/A
95	L2-1121-05	MPLV-4205	60-2112-02	N/A	N/A	N/A
96	L2-1121-06	MPLV-4206	60-2112-03	N/A	N/A	N/A
97	L2-1121-07	MPLV-4207	60-2112-03	N/A	N/A	N/A
98	L2-1121-08	MPLV-4208	60-2112-04	N/A	N/A	N/A
99	L2-1121-09	MPLV-4209	60-2112-04	N/A	N/A	N/A
100	L7-0048-80	MPLV-4702	N/A	N/A	N/A	62-7004-09
101	L7-0048-81	MPLV-4703	N/A	N/A	N/A	62-7004-10
102	L7-0200-14	MPLV-4701	N/A	N/A	6V-7020-00	N/A
103	L7-0203-71	MPL-6901	60-7016-08	N/A	N/A	N/A
104	L7-0203-74	MPL-6902	60-7016-09	N/A	N/A	N/A
105	L7-0412-00	LPL-7401	L6-0700-40	L6-1700-40	N/A	N/A
106	L7-0430-00	LPL-7400	L6-0700-40	L6-1700-40	N/A	N/A
107	L7-0431-00	LPL-7029	60-7043-00	61-7043-01	N/A	60-7043-01