

@ Copyright 1986-2024 by Vektek LLC ****See Vektek.com>Products>Maintenance for special tools

Vektek, Inc.	Instruction Sheet	IS	1003	
1334 East Sixth Ave. P.O. Box 625		REV:	F, I.A.W. ECN3130	
Emporia, Ks. 66801		REV. BY/DATE:	MAJ	11-3-16
U.S.A.		APPR/DATE:	GY	11-4-16
TITLE: Disassembly/Assembly Instructions: 1000, 1400, 2500 & 3000 Fluid Advance Work				

Supports

Read all instructions before disassembly

Refer to the illustration on page three for component part numbers and a tool list.

Disassembly

Notice: When disassembling multiple work supports, the plunger and body/sleeve assembly from each work support should be kept together.

- 1. Unscrew the body/sleeve assembly (9) from the base (15) or fixture. **Caution- Use a six**point socket only. Other types of wrenches may damage the work support.
- 2. Hold the plunger (6) stationary and unscrew the contact bolt (1). Remove o-ring (16) from contact bolt (1).
- 3. Remove the spring (2) and spacer (10) from inside the plunger (6).
- 4. Hold the piston (8) stationary and unscrew the cap screw (3).
- 5. Slide the plunger (6) out of the top of the body/sleeve assembly (9) and then push the piston (8) and spring (13) out of the retainer (14).
- 6. Remove the wiper (7) from the body/sleeve assembly (9). **Do not scratch the inner sleeve**.
- 7. Hold the body/sleeve assembly (9) stationary and unscrew the retainer (14) from the body/sleeve assembly (9) using a spanner wrench.
- Remove the piston seal (11) and piston seal back-up ring (12) from the piston (8), the O-ring (5) from the retainer (14) and the gasket (4) from the base (15) or fixture.
- 9. Clean all parts thoroughly and set aside to dry.


		1003		
Instruction Sheet	REV:	F, I.A.W. ECN3130		
	REV. BY/DATE:	MAJ	11-3-16	
	APPR/DATE:	GY	11-4-16	
TITLE: Disassembly/Assembly Instructions: 1000, 1400, 2500 & 3000 Fluid Advance Work				
		Instruction Sheet REV. BY/DATE: APPR/DATE:	Instruction Sheet REV. BY/DATE: MAJ APPR/DATE: GY	

Supports

Assembly

- 1. Lubricate all O-rings, gaskets, back-up rings and seals with clean hydraulic fluid (Vektek 65-0010-01 or equivalent). Apply Loctite primer N® or equivalent to the threads of the contact bolt (1) and the retainer (14) and set aside to dry.
- 2. Press the wiper (7) into the body/sleeve assembly (9) using only enough force to seat the wiper in the counterbore. **Caution:** Excess force may cause the inner sleeve to collapse.
- 3. First install the back-up ring (12) then the piston seal (11) onto the piston (8) with the sealing lips of the piston seal (11) toward the piston (8) base.
- 4. Install the O-ring (5) onto the retainer (14).
- 5. Apply Loctite 243® or equivalent to the threads of the retainer (14).
- 6. Hold the body/sleeve assembly (9) stationary and screw the retainer (14) into the body/sleeve assembly (9). Tighten to the torque specification on the parts list.
- 7. Slide the spring (13) onto the piston (8) and insert both parts into the retainer (14)
- 8. Insert the plunger (6) into the top of the body/sleeve assembly (9).
- 9. While holding the piston (8) stationary insert the cap screw (3) into the top of the plunger (6) and thread the cap screw (3) into the piston (8). Tighten to the specification on the parts list.
- 10. Insert the flat washer (10) and the spring (2) into the top of the plunger (6).
- 11. Install o-ring (16) onto contact bolt (1). Apply one drop of Loctite 243® or equivalent to the threads of the contact bolt (1). While holding the plunger (6) stationary tighten the contact bolt (1) to the plunger (6). Tighten to the torque specification on the parts list.
- Place the gasket (4) flat in the bottom of the base (15) or mounting cavity. Insert the work support assembly into the base (15) or mounting cavity and tighten it to the torque specification on the parts list.
 Caution- Use a six-point socket only. Other types of wrenches may damage the work support.

Vektek, Inc.	Instruction Sheet	IS	1003	
1334 East Sixth Ave.		REV:	F, I.A.W. ECN3130	
P.O. Box 625 Emporia, Ks. 66801 U.S.A.		REV. BY/DATE:	MAJ	11-3-16
		APPR/DATE:	GY	11-4-16
TITLE: Disassembly/Assembly Instructions: 1000, 1400, 2500 & 3000 Fluid Advance Work				
Supports				



Model Number	Tool List
10-0706-03	
10-0706-04	
10-0706-14	9/16 open end, 1/2 & 7/8 socket (six point)
10-0806-04	1/16 & 5/64 hex keys, spanner wrench
10-0806-05	
10-0806-15	5.
10-0708-06	
10-0708-07	
10-0708-17	3/4 open end, 5/8 & 1-1/8 socket (six point)
10-0808-06	1/8 & 3/32 (2) hex keys, spanner wrench
10-0808-07	
10-0808-17	

Page 3 of 3 FORM NO.